

#### For use on Articulating ladders



Match up the reversible "A" arm to the "A" post.



Turn the
"A" arm so
the "A" is
facing
toward the
Fuel Tank.



Pinch the end of the post and slide the arm onto the end of the post.



Insert the secure lock in the end of the post, making sure it is locked in place.



Repeat the entire process for the "B" post and arm.



Now it is ready for use on any of the Little Giant articulating ladders.



The Fuel Tank is designed to be used when the ladder is in the A-frame position attached to the upper inner section.

# For use on Select Step®



Put the reversible "A" arm on the "A" post, with the "A" on the arm facing out.



Insert the secure lock in the end of the post, making sure it is locked into place.



This is how it should look when put together correctly.



Repeat the entire process for the "B" post and arm.



Now it is ready for use on the Select Step.

#### For use on Little Giant Xtreme®



Put the "A" arm into the "B" post and the "B" arm into the "A" post, facing outword.



To attach to the Little Giant Xtreme ladder, slide the posts into the accessory posts.



To attach to the AirDeck, insert posts through the square holes.



Before using the Fuel Tank insert and secure the lock in the end of the post, making sure it is completely locked in place.



Now it is ready for use on the Little Giant Xtreme.

### Magnetic Mounting Bracket



The magnetic mounting bracket can be placed on any one of the four sides.



When attached to the long sides, the mounting bracket can hold two items: a paint brush to the magnet and a roller to the middle of the bracket. The bracket can also be used on the short sides of the Fuel Tank, but only to hold a paint brush.

## Paint and Peel Clean-up



Simply pour out any excess latex paint and store upside down to dry.



Let dry and remove the paint within 48 hours. Peel it away with ease, no liners needed. Your Fuel Tank will be clean and ready to use.